



Care Instructions for Achilles Clear PVC

Stock Code PVK_ _

To obtain maximum life from Achilles clear PVC the following should be observed:

- When washing surface stickiness or stains, dilute a neutral detergent with warm water, moisten a soft cloth, wring it out well, and then wipe the surface carefully.
- Ensure film is completely dry after washing, water remaining on film surface may cause acceleration of deterioration and permanent damage.
- If you wipe or rub a film surface too hard, scratch marks could result
- If neutral detergent is used, make sure you remove completely with water.
- Do not use any organic solvents, film surface and colour will be affected
- When a film absorbs water after rain or washing, the film will be foggy as whitish colour, the film will recover when completely dry
- Please note, if film is experienced getting wet and dry many times, the film may not recover to fully to initial colour
- If film temperature is more than 60 degree-c, the film may become extremely soft.
- In a case of using a film at colder temperature, strong impact to the film may cause cracking
- Fine cracks may occur on a film surface due to deterioration, please replace film.